

Tank Boss

Battery Information



SKF battery

24 volt battery pack easily attaches via slide lock on back of unit.



Linak battery

24 volt battery pack easily attaches via metal lock on back of unit.



It is OK to leave plugged in at all times if desired.

Battery can be recharged while on unit by plugging A/C adapter into bottom of control box. Light will be amber when charging and green when fully charged.

Battery can be recharged while on unit by plugging charging cord into bottom of control box. Two lights will be on - green for on and amber for charging. The amber light will go out when charge is complete.



Red emergency stop button:

~ **Push to stop**

~ **right twist a quarter turn to release and start**



A separate wall mounted charger unit is available for recharging additional batteries. (Sold separately)

SKF shown here, also available for Linak.

